



No.	Code	Description	No.	Code	Description
1	TA19210	HEX. SOC. HD. CAP SCREW ASSY	49	TA19346	TAPPING SCREW
2	TA19136	CYLINDER CAP	50	TA19341	E-RING
3	TA19137	EXHAUST SEAL	51	TA19215	O-RING 9215
4	TA19138	COMPRESSION SPRING	52	TA19342	HEX.SOC.HD.CAP.SCREW
5	TA19139	HEAD VALVE GUIDE	53	TA19338	STEP PIN
6	TA19140	O-RING 9140	54	TA19339	SPRING
7	TA19142	HEAD VALVE PISTON	55	TA19337	CLICK LEVER
8	TA19143	O-RING 9143	56	TA19352	SPRING PIN
9	TA19144	O-RING 9144	57	TA19333	PUSHER
10	TA19145	CYLINDER CAP SEAL	58	TA19334	PUSHER GUIDE
11	TA70377	MAIN PISTON UNIT	59	TA19335	SPRING
12	TA19208	CYLINDER WASHER	60	TA19344	SLIDER
13	TA19146	CYLINDER	61	TA19336	TAIL COVER
14	TA19148	CHECK PAWL	62	TA19306	WARNING LABEL
15	TA19149	CYLINDER RING	63	TA19348	NAME LABEL
16	TA19207	BUMPER	64	TA19209	O-RING 9209
17	TA70351	FRAME UNIT	65	TA19147	O-RING 9147
18	TA18930	NAME PLATE	66	TA19150	O-RING 9150
19	TA19180	SPRING PIN	67	TA19155	O-RING 9155
20	TA19328	NOZZLE	68	TA19159	O-RING 9159
21	TA19170	HEX. SOC. HD. CAP SCREW	69	TA19160	O-RING 9160
22	TA19171	HOOK	70	TA19161	O-RING 9161
23	TA19172	ELASTIC STOP NUT	71	TA19165	SPRING PIN
24	TA19168	END CAP SEAL	72	TA19173	EXHAUST FILTER
25	TA19169	END CAP	101	TA81265	O-RING KIT
26	TA19141	O-RING 9141	102	TA81266	TRIGGER VALVE KIT
27	TA19329	HEX.SOC.HD.CAP.SCREW			
28	TA19347	COLLAR B			
29	TA19156	TRIGGER VALVE HEAD			
30	TA19157	SPRING			
31	TA19158	TRIGGER VALVE STEM			
32	TA19162	TRIGGER VALVE GUIDE			
33	TA19163	SPRING			
34	TA19164	TRIGGER UNIT			
35	TA19198	ARM GUIDE			
36	TA19199	SPRING			
37	TA19200	CONTACT ARM A			
38	TA19201	C-RING			
39	TA19182	ADJUST DIAL			
40	TA19343	CONTACT ARM B			
41	TA19202	CONTACT TOP			
42	TA19052	HEX.SOC.HD.CAP SCR.ASSY			
43	TA19254	COLLAR			
44	TA19330	FRONT COVER			
45	TA19331	DRIVER GUIDE			
46	TA19332	WARE PLATE			
47	TA81276	MAGAZINE ASSY(USA)			
48	TA19340	PUSHER STOPPER			